

To Switch Base

Wiring for the back lighting on the RF switch pad includes 3 wires for connection. The RED is used to back light the individual switches when they are turned on and should be connected to switched ignition.

The WHITE wire is for the backlighting behind the switches and can be connected to the headlamp circuit <u>OR</u> to the same place as the red wire (switched ignition). This allows the backlighting to come on only when the headlights are on.

The black wire is for ground.

www.triggercontroller.com